

## GenPole Wheelbase

NOTE: A generator should not be run in or in close proximity to a living area. Allow components to cool after running generator before touching.

### **Installation:**

1. Place wheel base on flat surface with flagpole holder in the vertical orientation.
2. Center wheel of vehicle onto base with the flagpole holder column a safe distance from vehicle.
3. Insert flagpole into base, making sure the pole is inside each of the internal rings of the wheelbase.

### **Removal:**

1. After lowering the flagpole completely, remove the flagpole from the base.
2. Drive the vehicle off the base.
3. Wipe off any exhaust condensation from the inside of the base. It is normal for water to be present at the base during operation.

Positive feedback is greatly appreciated, but if you are not satisfied, please contact us.

See us at: <https://genexhaust.com/>